


Power Wheel® Service Manual

Model 8 Double Reduction Wheel Drives With Integral Parking Brake Option




PHONE: (219) 925-3200
FAX: (219) 925-4725



IDENTIFICATION

IMPORTANT: All Power Wheel units and kits are shipped with a nameplate that includes the Auburn Gear part number and order code as shown.



In addition to the nameplate, Power Wheel drives are stamped with an identification number which appears on the cover or hub flange as shown.

Example: **6000236-A-4-9**

When ordering parts, the information included on the nameplate or the stamped identification number is necessary to accurately identify the drive and obtain the correct replacement parts. Once this information has been obtained, contact Auburn Gear for the appropriate parts list.

DISASSEMBLY OF POWER WHEEL

STEP 1

If brake portion of drive is to be serviced remove motor from planetary drive. Temporarily install two 1/2-13 x 1.25 screws into hydraulic motor mounting holes and torque to 50 lb. ft. (67 Nm). These must be used to hold spring back-up plate in position when parking brake assembly is removed from the drive. If the brake portion of drive does not require service go to step 5.

STEP 2

Remove the four T-50 Torx head screws (1) holding the parking brake assembly in position. It may be necessary to lightly strike the piston assembly (2) with a rubber mallet to loosen from spindle or cover.

STEP 3

Remove disc pack (3) from drive only if necessary. Be careful to maintain discs in order.

STEP 4

If brake piston assembly (2) has been removed slide the coupling (4) and retaining ring (5) from splines on input shaft (6). Remove sleeve bearing (7) if replacement is required.

STEP 5

Position the assembly upright on face of spindle (9).

STEP 6

Remove the disengage cover (35) if necessary.

STEP 7

Remove twelve bolts (33), flat washers (32), and large cover (31) from the unit. The thrust washer (28) and the disengage plunger (29) will usually remain attached to the large cover (31) when it is removed. Remove thrust washer (28), disengage plunger (29) and "O" ring (30) from the large cover (31).

STEP 8

Remove primary sun gear (27) from end of input shaft (6).

STEP 9

Remove primary carrier assembly (26).

STEP 10

Remove the secondary carrier assembly (25). It may be necessary to remove the ring gear (23) first, if difficulty is encountered in removing the carrier.

STEP 11

Remove the input shaft (6) from spindle (9). Remove the retaining rings (20), washers (21), and spring (22) from input shaft (6) only if replacement is required.

STEP 12

If not previously removed (see step 10) remove ring gear (23) from hub (15). It may be necessary to strike ring gear (23) with a rubber mallet to loosen from hub (15).

STEP 13

Remove the retaining ring (19) from in front of the thrust washer (18) and lift hub (15) from spindle (9). If bearings are not a loose fit, it may be necessary to press spindle (9) from hub (15). **NOTE:** Use a retaining ring expander tool to remove retaining ring (19).

STEP 14

If included on unit, remove boot seal (10) from hub (15). Remove the oil seal (11) and bearing cones (12 & 17) from hub (15). Inspect bearing cups (13 & 16) in position and remove only if replacement is required.

ASSEMBLY OF POWER WHEEL

STEP 1

Press new bearing cups (13 & 16) in each side of the hub (15). It is recommended that bearing cups (13 & 16) and cones (12 & 17) be replaced in sets.

STEP 2

Assemble bearing cone (12) into cup (13) at seal end of hub (15) and press a new seal (11) into hub (15). Install boot seal (10) on hub (15) if unit is so equipped.

STEP 3

Position spindle (9) upright on bench. Lubricate lips of seals (10 & 11) and lower hub (15) onto spindle (9). Hub (15) should be centered as it is lowered over spindle (9) to prevent seal damage.

STEP 4

Assemble bearing cone (17) over spindle (9) and into bearing cup (16). If bearings (12, 13, 16, & 17), hub (15) or spindle (9) is replaced, a new retaining ring (19) is required for proper bearing setting. Do not re-use snap ring after it has been installed and removed from unit. Select the thickest retaining ring (19) that can be assembled into the ring groove of the splined end of spindle (9) above bearing cone (17). Bearing should have from .000 – .006 inches (.00 – .15mm) of end play when proper retaining ring (19) is installed.

STEP 5

Assemble a washer (21), spring (22), a second washer (21), and a retaining ring (20) in the middle groove of input shaft (6). Assemble a second retaining ring (20) in groove opposite pilot end of input shaft (6). Some shafts have a shoulder and require only one retaining ring (20).

STEP 6

Assemble the splined end of the input shaft (6) down into spindle (9).

STEP 7

Assemble secondary carrier assembly (25) to spindle (9) at splines.

STEP 8

Clean mating surfaces and apply a bead of silicone sealant to face of hub (15) that mates with ring gear (23). (See instructions on sealant package). Position ring gear (23) on hub (15) being careful to align bolt holes.

STEP 9

Assemble the primary carrier assembly (26) into the ring gear (23). It will be necessary to rotate carrier to align secondary sun gear (part of primary carrier assembly (26)) with planet gear teeth in secondary carrier assembly (25). Assemble primary sun gear (27) over input shaft (6). Rotate primary sun gear (27) to align input shaft (6) to gear splines and gear teeth in primary carrier assembly (26).

STEP 10

Lubricate "O" ring (30) and assemble in groove inside cover hole, push plunger (29) into cover with pointed end facing inside of unit.

STEP 11

Assemble the thrust washer (28) with tangs engaged with cover (31). **NOTE:** A small amount of grease applied to the back side of thrust washer (28) will hold washer in place. Apply a bead of silicone sealant to end face of ring gear (23). Assemble cover (31) aligning holes of cover and ring gear. Assemble the twelve flat washers (32) and 3/8 – 16x5 1/2 inch hex head bolts (33). Torque bolts to 45 – 50 lb. ft. (61 - 67 Nm).

STEP 12

Assemble the disengage cover (35) with dimpled center protruding out if wheel is to be used to drive the vehicle. Assemble and torque the two 5/16–18 bolts (36). Torque bolts to 10 – 20 lb. ft. (13 – 27 Nm).

STEP 13

Invert the Power Wheel assembly and assemble the sleeve bearing (7), coupling (4) and retaining ring (5) with counterbore out to the input shaft (6).

STEP 14

The proper disc pack and piston cylinder assembly will depend on the Power Wheel brake model number: Contact Auburn Gear for specific part numbers. Disc packs are supplied as a matched set. Replacement packs are packaged individually to retain the matched characteristics. After removing from package pre-soak the disc pack in the oil used in the Power Wheel drive before placing into the unit. Take care to keep disc pack (3) in proper order and separate from other disc packs.

STEP 15

Align the tangs on the steel separator plates and carefully place the complete disc pack (3) into the Power Wheel drive so that the tangs on the separator plates are within the slots in the drive. Also, the spline on the friction discs should be aligned with the spline on the Power Wheel adapter coupling (4). Check to make sure that the disc pack is properly seated.

STEP 16

Clean seal surface of the drive and piston assembly (2) of any old sealant and wipe any oil from seal surface of spindle or cover. Most piston kits include a gasket (8) which should be placed on spindle face to seal interface with piston assembly. If no gasket is included apply a continuous 1/32 bead of silicone sealant to seal surface on inside of the bolt circle. **NOTE:** Do not use excessive amount of sealant as this can interfere with proper operation of the parking brake.

STEP 17

Align the four piston assembly holes with the four holes in the Power Wheel spindle. Apply Locktite 262 to the four screws (1) to be installed and torque to 80 – 94 lb. ft. (108 – 127 Nm).

STEP 18

Remove the two screws installed in motor mounting holes.

STEP 19

Before using the brake, it is recommended that a pressure release check be performed. Using a suitable hydraulic source, bleed the air from the brake and pressurize the brake to the specified release pressure. The brake plates should now turn freely. If the hydraulic source will provide at least 1000 PSI pressure, apply 1000 PSI and check to make sure that the pressure does not decay more than 30 PSI in 60 seconds.

STEP 20

After motor is assembled to drive or drive is sealed at spindle, fill with lubricant to proper level and replace all plugs.

NOTE: When installing a hydraulic motor to the Power Wheel drive it is necessary to place an “O” ring or gasket (not supplied by Auburn Gear) between the motor and the planetary drive. “O” ring sizes: SAE A 2-042, SAE B 2-155, SAE C 2-159.

CARRIER ASSEMBLIES

It is recommended that the secondary and primary carrier assemblies (25 & 26) be serviced in their entirety to protect the integrity of the Power Wheel drive.

LUBRICATION RECOMMENDATIONS

IMPORTANT: POWER WHEEL PLANETARY DRIVES ARE SHIPPED WITHOUT LUBRICANT AND MUST BE FILLED TO THE PROPER LEVEL PRIOR TO START UP.

Observe lubrication recommendations given by the original equipment manufacturer. When specific recommendations are not available, use mild extreme pressure lubricant API-GL-5, No. 80 or 90 when filling the Power Wheel under normal temperature ranges between 0 - 120°F (-18 to 49°C). Power Wheel is to be half full of oil when unit is mounted level and horizontal. Use drain and fill plugs located in cover and ring gear. Oil is to be changed after first 50 hours of operation with subsequent changes every 1000 hours or yearly, whichever comes first. If unit is to be operated vertically, if ambient conditions are outside the specified range, or if the oil temperature exceeds 200°F (93°C) contact Auburn Gear for oil and level recommendations.

TOWING VEHICLE

CAUTION: The Power Wheel will not normally be damaged by towing; however, the hydraulic drive components may be damaged unless the Power Wheel is disengaged from the drive motor. Road speeds in excess of 25 MPH should be avoided unless clearly specified to be permissible by the equipment manufacturer.

TO DISENGAGE POWER WHEEL

CAUTION: For units equipped with the standard spring disconnect, assemble the disengage cover (35) with the dimpled center protruding inward. For units equipped with the optional quick disconnect, push in center plunger of disconnect. **PARKING BRAKE WILL NOT FUNCTION IF UNIT IS DISENGAGED.**

STORAGE

A protective film is applied to the Power Wheel at the factory to prevent rust during shipment. Additional protection may be required if the Power Wheel is to be stored for an extended period of time.

SEALING COMPOUND

Silastic RTV732 sealer and General Electric Silimate RTV No. 1473 or RTV No. 1503 are currently recommended for sealing gasket surfaces. Sealant should be applied in a continuous bead, which should be centered on the surface to be sealed but should move to the inside of the hole at each bolt hole location. For service requirements order Auburn Gear part number 604101.

SPECIFICATIONS

Maximum intermittent output torque	100,000 lb. in. (11,300 Nm)
Maximum input speed	2,500 RPM
Oil capacity	52 oz (1,540 ml)
Maximum parking brake release pressure	3,000 PSI (206 bar)

ITEM NO.	DESCRIPTION*	NO. USED IN ASS'Y.	ITEM NO.	DESCRIPTION*	NO. USED IN ASS'Y.
1	Torx Head Screw 618320	4	21	Washer	2
2	Piston Assembly	1	22	Disengage Spring	1
3	Disc Pack	1	23	Ring Gear	1
4	Coupling	1	24	Magnetic Plug 14-00-052-002	1
5	Retaining Ring	1	25	Secondary Carrier Assembly	1
6	Input Shaft	1	26	Primary Carrier Assembly	1
7	Sleeve Bearing 612701	1	27	Primary Sun Gear	1
8	Brake Gasket	1	28	Thrust Washer	1
9	Spindle	1	29	Disengage Plunger 610801	1
10	Boot Seal 604405	1	30	"O" Ring 614101	1
11	Oil Seal 14-00-044-011	1	31	Large Cover	1
12	Bearing Cone 14-00-133-007	1	32	Flat Washer	12
13	Bearing Cup 14-00-133-006	1	33	Hex Head Bolt	12
14	Wheel Bolt	8-10	34	Pipe Plug 605204	1
15	Hub	1	35	Disengage Cover 14-02-039-005	1
16	Bearing Cup 14-00-133-008	1	36	Hex Head Bolt	2
17	Bearing Cone 14-00-133-009	1	37	Quick Disconnect Gasket	1
18	Thrust Washer	1	38	Quick Disconnect Assembly	1
19	Retaining Ring Kit 14-05-410-001	1	39	Hex Head Bolt	2
20	Retaining Ring	2			

* Contact Auburn Gear with part number and order code of drive to obtain the appropriate parts list. Refer to parts list for the specific part numbers and quantities.

Model 8 Power Wheel® Service Kits

Part No.	Description	Included Items
14-05-410-001	Retaining Ring Kit	19 (6 Retaining Rings)
641011**	Bearing and Seal Kit	11, 12, 13, 16, 17, 19 and 30
641018**	Seal Kit	11, 19, and 30

** Indicates kit also includes a tube of sealant, part number 604101.